



TIPS FOR SUCCESSFUL CORK INSTALLATIONS

TECHNICAL SUPPORT 800.345.6202.

ACCLIMATE TILE ON SITE AS INSTRUCTED. 3 TO 5 DAYS IS REQUIRED.

CORK IS NATURAL. SHADE VARIATIONS FROM TILE TO TILE ARE INHERENT. INSTALLER IS RESPONSIBLE FOR FINAL BLENDING OF SHADES. CLAIMS ARE NOT ACCEPTED ON SHADING OR OTHER VISUAL DEFECTS AFTER INSTALLATION.

USE THE RECOMMENDED TROWEL AS SUPPLIED WITH MATERIAL. EXPANKO 2260 ADHESIVE HAS A 15-MINUTE RULE. INSTALL TILES AND ROLL WITHIN 15 MINUTES OF TROWELING THE ADHESIVE. DO NOT LAY TILES IN ADHESIVE THAT IS CURED. IF THE ADHESIVE DOESN'T TRANSFER TO THE TILE, IT WON'T ADHERE. PAY ATTENTION TO AIR MOVEMENT, DIRECT SUNLIGHT, HEAT AND HUMIDITY.

DO NOT DRY LAY TILE. INSPECT TO VERIFY TILE IS CORRECT AND PLACE BACK INTO BOX. CURLED TILES ARE NOT TO BE INSTALLED.

CORK IS NOT LIKE VCT. ADHESIVE TRANSFER, SHADE BLENDING AND QUALITY INSTALLATION IS CRITICAL. CORK IS A HIGH END FLOORING MATERIAL AND CUSTOMERS REQUIRE A HIGH END INSTALLATION.

TIGHTEN SEAMS BY APPLYING FOOT PRESSURE EVERY FEW COURSES. THE TIGHTER THE BETTER.

READ THE DETAILED INSTRUCTIONS (*DOCUMENT ID: 110*). IF YOU DON'T HAVE THEM, OBTAIN THEM. ALL TECHNICAL INFORMATION AND DOCUMENTS ARE AVAILABLE AT WWW.EXPANKO.COM.